

EVO PRO & FORCE PRO

Remote Guide



Get the most out of your Android TV™ with Google Assistance built in Android TV provides a smarter viewing experience. Watch blockbuster movies, stream apps and enjoy multiplayer games. And, with the Google Assistant built in, you can do more faster. Ask it questions, discover the best content and control smart devices around your home – all with just your voice.






How to pair an EVO Pro remote to a TV


Step 1

From the home screen, go to Settings at the top right-hand corner.




Step 2

Once in the settings menu, select the Device Preferences option.




Step 3

Once in the Device Preference section, scroll down to Smart Control.




Step 4

From here, follow the instructions on the screen. Locate or type in your TV brand name.





Step 5

Then, follow the on-screen instructions. The Power button test is first.



Step 6

Next is the Input/Source button to check if the TV is capable of changing inputs and conduct a volume test.



Once complete, it will say the setup was successful.

Note: You can press the remote's **Home** button or **MYTV** button to exit the TV brand select screen.

If you are pairing an EVO Pro replacement remote, use the pairing steps below:

Pair EVO Pro remote (replacement)

- Press and hold the **Home** and **Back** buttons at the same time until the red light flashes quickly. Then, release the buttons.
- Wait a few seconds without pressing any buttons until you see a message indicating that the pairing was successful.
- Follow the steps above to pair the remote to your TV.

*If you are trying to connect a universal remote, refer to the remote manual to confirm compatibility with the EVO Pro.